



STARTING THE ENGINE (...continued)

- 9. Grasp the starting handle firmly in one hand - but do not wrap your thumb around the handle. Keep it on the same side as your fingers - this is very important. You thumb could be broken if you wrap it around the handle, and the engine kicks back.
10. Crank the engine strongly before lowering the decompression lever smoothly. The engine should fire up. If it doesn't, go through the steps again from instruction 7 above.
11. If the engine is now running, slide the handle off the shaft.
12. If you let go of the handle when the engine fires up, do not try to grab it. Stop the engine using the stop control. Then start the engine again.
13. Never stop the engine using the decompression lever. This may damage the engine and will be regarded as misuse by the hire company. Only use the proper RUN/STOP control.

USING THE VIBRATING ROLLER

- 1. Wear your protective equipment including safety boots and gloves. Always keep your hands, feet and clothing away from moving parts of the roller.
2. Hold the handlebars of the vibrating roller firmly with two hands before pulling the control lever in - the steering arm may move unexpectedly as the drive is taken up.
3. This roller can be turned and maneuvered easily using the engine to

drive it forwards and backwards. Take care not to strain yourself by trying to move it with the drum or engine stopped.

- 4. Check that there are no obstructions behind you before you drive the roller in reverse. Release the control lever straight away if you need to stop.
5. Make sure that any support jack has been retracted before you start work.
6. If your roller has a water sprinkler system, use it to help prevent the compacted surface sticking to the drum.
7. Watch out for signs that vibration may be affecting your hands. If your fingers start to tingle or feel numb, take a short break from using the roller. Exercise your fingers to encourage blood circulation.
8. To help prevent vibration affecting your hands, operate the roller for shorter periods. Keep your hands warm, - wearing gloves may help do this.
9. Do not operate the vibrating action on very hard surfaces such as concrete or frozen ground.
10. If an obstruction becomes jammed in the drum scraper, or something gets tangled in the drive mechanism, you must stop the engine before you clear it.
11. Stop the engine if leaving the machine unattended.
12. If your equipment does not work properly do not attempt to repair it. Contact the hire company.

Vibrating Roller

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read this entire leaflet BEFORE using the Vibrating Roller

- 1. Plan your work and think ahead to make sure you will always be working safely.
2. Diesel is highly flammable. Take care not to cause a fire or explosion.
3. This vibrating roller is designed to compact crushed hardcore, backfill, asphalt and other road surfacing materials on level surfaces or gently slopes.
4. The action of this vibrating roller can cause injury or damage if the machine is not used in a careful and controlled way.
5. If you have not used a vibrating roller before, familiarize yourself with the machine on some straightforward work before you start on the main task.
6. You must have at least the following items of personal protection equipment: ear muffs or plugs giving protection for levels up to 96 dB(A); safety boots to EN345 or BS1870/4972; gloves.
7. This machine must not be used by minors, or by anyone under the influence of drugs or alcohol.
8. This vibrating roller is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Please keep this leaflet safely as it may be required for future reference



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

Copyright Hire Association Europe April 2011

Any unauthorised reproduction - manually or electronically - is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600
Email: mail@hae.org.uk
website: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



(continued overleaf...)

- 1. This section describes the starting procedure for most diesel-engined vibrating rollers. If the hire company has given you special instructions, follow them. Otherwise, follow the instructions given you.
2. Your engine may have a low oil warning system that will prevent the engine starting if the oil level is too low, or if the machine is on too great a slope. Check the oil level before you try to start the engine. Do not use the roller on slopes that are too steep.
3. Move the STOP control to the RUN position.
4. Check that the throttle lever is in the IDLE position.
5. Do not wear gloves when you start the engine. Also, make sure that you have no loose clothing or flapping sleeves that could get caught.
6. Fit the starting handle to the shaft, and check by turning it anti-clockwise that the ratchet mechanism works. Check also that the handle slides on and off the shaft easily.
7. Move the decompression valve lever into the decompression position.
8. If the engine is fitted with a cold start button, press it in when starting from cold.

- 1. No smoking.
2. Stop the engine and let it cool down.
3. If possible move the machine away from your work area.
4. Check that you know which is the diesel tank as your machine may also have a water tank.
5. Clean the filler cap and the area around it to prevent dirt falling into the fuel tank.
1. Check your machine, engine, and all equipment - contact the hire company. Do not use anything found damaged - contact the hire company.
2. Damaged that the steering arm is at a suitable height for you, and that the steering arm lock has been locked after any adjustment.
3. Your roller may have a water sprinkler system to help prevent the compacted surface sticking to the drum. Top up the water tank before you start work. If your roller does have a water tank, ensure you know which tank is for water and which is for diesel fuel.
4. Vibration from using this vibration roller can be hazardous. Warm your hands up before you start work, and wear gloves to keep your hands warm while you are working.
5. Make sure that you understand all of the controls. Before you start the machine, you must know how to stop it.
1. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
2. This equipment is likely to cause noise levels up to 96 dB(A) - wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
3. You must wear safety boots (EN345 or BS1870/4972).
4. Make sure you have no loose or flapping clothing, or long hair, that could get caught in the roller.



Before Starting Work...

- 1. Anybody who is working near to you will also need to wear appropriate personal protective equipment.
2. Check your machine, engine, and all equipment. Do not use anything found damaged - contact the hire company.
3. Make sure that the area is clear and safe and that no-one is near to you or could distract you.
4. Protect other people from the noise and from injury. Warn others to keep away and that no-one is near to you or could be injured.
5. The vibrating roller may damage pipes or cables laid just beneath the surface. Do not use this roller on slopes where you may have difficulty controlling it. Contact the hire company if you need a machine to do this.
6. Do not use this roller on slopes where you have difficulty controlling it. Contact the hire company if you need a machine to do this.
7. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection.
8. This equipment is likely to cause noise levels up to 96 dB(A) - wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
9. You must wear safety boots (EN345 or BS1870/4972).
10. Make sure you have no loose or flapping clothing, or long hair, that could get caught in the roller.

WORK AREA